

## Important Safety Instruction

1. Before using it, please ensure that you have checked and installed all the parts and accessories of the AF200 / AF205 Auto-Fill pet water fountain. **(Refer to the 'Product Installation Steps' as shown.)** This will help prevent issues like water leakage, insufficient water levels, and overflow during automatic refilling, or operational failures etc.
2. Before plug in the power, please make sure that both your hands and the plug are dry to prevent electric shock.
3. Before cleaning or replacing the filter cartridge, you should disconnect the power and take out the water quick connector.
4. The power adapter and USB plug must not be flooded during cleaning.
5. To prevent cross-infections and maintain your pets' health, it is recommended that each pet has its own water fountain.
6. If you have multiple pets, you can connect several AF200 / AF205 for each pet's own water fountain supply. **(Refer to "Product Installation Steps" Step11 as shown).**
7. AF200 / AF205 come with a 1/2-inch Female threaded connector. If your faucet does not have a 1/2-inch Male threaded connector, please purchase an adaptor that can connect to a 1/2-inch female threaded connector before connecting to the faucet and HAMCO AF200 / AF205

## Important Safety Instruction

8. Please always turn on the faucet when using this device; it will automatically fill the water tank at any time. You don't have to worry about the danger of insufficient water.
9. Before using the filter cartridge, please rinse it with water and soak it in water for 5-10 minutes.
10. After completing the entire assembly, then turn on the faucet. Allow the faucet water to fill the tank until the water level reaches to flood the pump, which will take about 5-10 minutes. Then, plug in the USB power supply.
11. When use this device, please make sure to lock the "lock ring" to prevent accidental opening of the fountain lid by pets, which could result in water leakage. ( Refer to "Product Installation Steps" Step6 as shown)
12. AF200 / AF205 quick connectors have a water-stop function. When cleaning, you only need to pull out the quick connector on the fountain lid without turning off the faucet.
13. Please use indoors only. Clean and maintain it every 2-4 weeks regularly, and replace the filter cartridge to ensure the smooth operation of the fountain and provides clean drinking water for your pets.
14. Replace the Installation set ( LLDPE tube, quick connector, ... ) every 1-2 years to provide clean drinking water for your pets.

## Important Safety Instruction

15. Place the product on a flat surface when the equipment is being used.
16. The USB cable clip should be fixed in the recess of the water tank wall. Do not move the position of the USB cable clamp (too long USB cable inside the tank will interfere with the operation of the automatic water filler and prevent it from refilling or overflowing automatically). (**Refer to “Product Installation Steps” Step1 as shown**).
17. Ensure that the "automatic water filler" securely pressed into the fountain lid, as it may cause in less than water level or overflow during the water replenishment process. (**Refer to “Product Installation Steps” Step3 as shown**)
18. Ensure that the Fountain lid and the tank are securely fixed together. If they are not tightly connected, it may lead to overflow during the water replenishment process. (**Refer to “Product Installation Steps” Step5 as shown**)
19. Please use the food grade installation kit provided by HAMCO to connect the faucet, Do not use non-food grade water tube such as garden hose..., as it will lead to water pollution.