













Product Installation Steps

| Step1 | Step 2-1 |
|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
|  |  |
| <p>Install the pump ,fixed USB cable clip and place the filter box</p> | <p>First, rinse with water and then soak the filter cartridge in water for about 5 minutes</p> |
| Step 2-2. | Step 3 |
|  |  |
| <p>Put the filter cartridge into the filter box.</p> | <p>Insert the Auto-Water Filler into the back of the fountain lid and press it tightly.</p> |

Product Installation Steps




| Step 4 | Step 5 |
|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|  |  |
| <p>Insert the pump's water tube into the back of the fountain lid</p> | <p>Press and fix the installed fountain lid back onto the water tank</p> |
| Step 6 | Step 7 |
|  |  |
| <p>Lock "lock ring" to prevent pets opening and leaking.</p> | <p>Insert the LLDPE tube and lock it with the quick connector together.</p> |

Product Installation Steps




| Step 8 | Step 9 |
|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |  |
| <p>Connect the quick connector onto the adapter of the lid.</p> | <p>Lock "1/2-inch female threaded connector" into the faucet and open the faucet, wait for about 5-10 min. letting the water level exceed PUMP, and plug in the USB power.</p> |
| Step10 | Step 11 |
|  |  |
| <p>Keep the faucet turned ON. It will automatically fill in the water tank when the water level drops.</p> | <p>Connect several Hamco AF series for each pet's own water fountain supply.</p> |

Product Installation Steps

How to assemble a quick fitting tees and Tubes.

| Step 1 | Step 2 | Step 3 |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
|  |  |  |
| Insert the LLDPE tube to the end of the quick fitting union tee. | Attach C-clip to prevent the Tube from falling out. | Assembly completed. |

How to disassemble a quick fitting tees and Tubes

| Step 1 | Step 2 | Step3 |
|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|  |  |  |
| | Remove the C-clip. | Pull out the tube. |